

# Installation instruction

## Volvogue Heavy Load Blocks

**Congratulations with your new set of Volvogue Heavy Load Blocks!**

The installation is quite simple, and can be done without any special tools. The brief description below works for all type 240's.

### Installation Material

- Two sets of bolts and nuts (included)

### Installation Guide

1. Jack up one side of the car and remove the wheel
2. Put another jack under the rear trailing arm
3. Remove the lower bolt of the rear shock absorber mounting
4. Remove the bolt/plate that secures the coil spring to the trailing arm
5. Gently lower the jack under the trailing arm so that the coil spring is off pressure
6. Put the Heavy Load Block under the spring with the new bolt thru the securing plate (you can easily press out the old bolt from the plate, if it is rusty, sometimes a hammer will to the job)
7. Jack up the trailing arm and put in the bolt for the shock absorber again
8. Be sure to tighten all bolts (shock absorber, coil spring and wheel)!



*Enjoy this genuine touch for your classic Volvo! The Volvogue team.*